

MaxEye Digital Video Signal Generation Toolkit

DVB-S2

Version 1.0.3.2

Getting Started Guide

Contents

1. Introduction	3
2. Installed File Location	3
3. Programming Examples	3
3.1. Create and Download Waveform.....	4
3.1.1 MaxEye DVB-S2 RFSG Generate Multiple Frames	4
3.2. Create and Save Waveform in File	9
3.3. Play Waveform from File	10
3.4. Play Waveform from File (USRP).....	11
3.4.1 MaxEye DVB-S2 USRP Play Waveform from File	11



1. Introduction

MaxEye Technologies provides generation functions in LabVIEW for generating the standard complaint signals for various digital video broadcasting standards. This guide explains how to use the DVB-S2 signal generation toolkit using the programming examples.

2. Installed File Location

The example VIs are installed in, <LabVIEW>\vi.lib\addons\MaxEye\Digital Video Toolkits\DVB-S2 Generation\Examples.

The toolkit help files are installed in, <LabVIEW>\vi.lib\addons\MaxEye\Digital Video Toolkits\DVB-S2 Generation \Documentation.

The toolkit API files are installed in, <LabVIEW>\vi.lib\addons\MaxEye\Digital Video Toolkits\DVB-S2 Generation\Generation\API.

You can also find a shortcut to the above location from the windows start menu.

Start->All Programs->MaxEye->Digital Video Toolkits->DVB-S2<LabVIEW>->Generation

3. Programming Examples

The DVB-S2 Signal generation toolkit contains examples for performing the following:

- i. Creating the waveform based on the standard specific user input parameters and then downloads the waveform to NI RFSG.
- ii. Creating the waveform based on the standard specific user input parameters and then writes the waveform to the file.
- iii. Playing the waveform using NI RFSG and NI USRP.

The programming examples are created using the LabVIEW API VIs. For more information about the API VIs used in the example VIs refer to the MaxEye DVB-S2 Signal Generation Help.chm document, accessible at Start->All Programs->MaxEye->Digital Video Toolkits-> DVB-S2 <LabVIEW> ->Generation->Documentation.

For more information please contact info@maxeyetech.com

3.1. Create and Download Waveform


DVB-S2 is based on the ETSI standard EN 302 307 V1.3.1 (2013-03). The system is intended to provide Direct-To-Home (DTH) services to the consumer. DVB-S2 transmits MPEG-2 and MPEG-4 TS stream in its single carrier. The toolkit has an example to demonstrate the functionality of creating DVB-S2 waveform, writing the waveform to the NI RFSG memory and then playing the waveform from the memory.

3.1.1 MaxEye DVB-S2 RFSG Generate Multiple Frames

This Example is used to generate multiple DVB-S2 frames. TS stream is used for generating the signal. The figure below shows the front panel of the Example VI.

The user configurations are divided in to four categories

- i. Hardware Settings
- ii. DVB-S2 Global Settings
- iii. Digital Video Payload Control Settings
- iv. Stream Configuration Settings
- v. Impairment Settings



For more information please contact info@maxeyetech.com



3.1.1.1 Hardware Settings

Hardware Setting

RFSG Resource
RFSG

Carrier frequency (Hz)
1.700000G

Power Level (dBm)
-10.00

External Attenuation (dB)
0.00

Headroom (dB)
5

Arb:Pre-filter Gain (dB)
-1

Reference Source
PXI_CLK

Frequency (Hz)
10.000M

Clk Output Terminal
Do not export signal

RFSG Resource – Configure the resource name used in NI Measurement and Automation explorer for the NI PXIe-5673/5673E device.

Carrier Frequency (Hz) – Center Frequency of the DVB-S2 signal in Hz.

Power Level (dBm) – Average Power level of the signal in dBm.

Headroom (dB) – Configure the Headroom value higher than PAPR of the signal to be generated. Refer MaxEye DVB-S2 Signal Generation Help.chm.

External Attenuation (dB), Arb: Pre-filter Gain (dB), Reference Source, Frequency (Hz), Clk Output Terminal – Refer NI RFSG Signal Generators help file.

3.1.1.2 DVB-S2 Global Settings

The Signal Settings includes the DVB-S2 standard specific configuration. Help files for each of the properties are available in DVB-S2 Signal Generation Help.chm file.

DVB-S2 Global Setting

Number of Frames	Symbol Rate, Hz
1	10M
Input Stream Type	Pulse Shaping Filter Type
Single Stream	Root Raised Cosine
Number of Streams	Roll-off Factor
1	0.35
Input Stream Format	Samples Per Symbol
Transport	2
Input Stream Synchronization Type	Filter Length, Symbols
Inactive	60
ISCR Type	Coding and Modulation Type
Short	Constant Coding
Null Packet Deletion Type	Pilot Insertion Enabled ?
Inactive	True

The Number of Frames property decides the Play Duration of waveform in seconds. To generate longer duration of the waveform increase the Number of Frames.

3.1.1.3 Digital Video Payload Control Settings


MaxEye Digital Video Toolkit allows you to configure various payload settings. The possible payload options are

- i. PN Sequence – In this mode configure Sync Insertion Enabled, Payload PN order and PN Seed properties and the toolkit ignores other properties in the Digital Video Payload Control. The toolkit generates pseudo random sequence based on the PN order and seed value, the generated bit sequence is used as a payload for generating the signal. Use this mode for testing the receiver performance for random payload values. When the number of super frames is more than 1 then the toolkit maintains payload continuity across the super frames.
- ii. User defined bits – In this mode configure Sync Insertion Enabled and Payload User Defined Bits property and the toolkit ignores other properties in the Digital Video Payload Control.
- iii. Test Pattern – In this mode configure Sync Insertion Enabled and Payload Test Pattern property and the toolkit ignores other properties in the Digital Video Payload Control. The possible values for the Test Pattern are All 1s, All 0s, 10101010 and 01010101. This mode is used for generating signal with known test patterns.

For more information please contact info@maxeyetech.com

- iv. Test File – In this mode configure the Sync Insertion Enabled and Payload File Path property and the toolkit ignores other properties in the Digital Video Payload Control. This mode is used for generating signal with the data from the file.
- v. MPEG2TS File(s) – In this mode configure the MPEG2 TS Number of TS Files and MPEG2 TS File Path property and the toolkit ignores other properties in the Digital Video Payload Control.



If the Sync Insertion Enabled property is set to True, the toolkit inserts MPEG2 TS packet sync byte (0x47) after every 187 bytes. The length of the TS packet is 188 bytes and the first byte is a sync byte (0x47).



3.1.1.4 Stream Configuration Settings

MaxEye Digital Video Toolkit allows you to configure various stream specific properties such as Code Rate, Modulation Type, FEC Frame Type, Input Stream Identifier and Payload settings.

For more information please contact info@maxeyetech.com



3.1.1.5 Impairment Settings

MaxEye Digital Video Toolkit allows you to configure various impairment settings.

For more information please contact info@maxeyetech.com

Impairment Setting

Impairments Enabled ?
 False

AWGN Enabled <input type="checkbox"/> False	I DC offset, % <input type="text" value="0.00"/>
Carrier to Noise Ratio, dB <input type="text" value="0"/>	Q DC offset, % <input type="text" value="0.00"/>
Frequency offset, Hz <input type="text" value="0"/>	IQ gain imbalance, dB <input type="text" value="0.00"/>
Clock Offset (PPM) <input type="text" value="0"/>	Quadrature skew, deg <input type="text" value="0.00"/>


If the Impairment Enabled property is set to True then the toolkit adds the impairments to the generated signal as per the user configuration for the supported impairments. Help files for each of the properties are available in DVB-S2 Signal Generation Help.chm file.

3.2. Create and Save Waveform in File

This Example is used to generate multiple DVB-S2 frames and the generated waveform is stored in a file for play back. Use this example

- ◆ To generate and store the custom waveforms based on your test requirement.
- ◆ To avoid generating the waveform at the beginning of your test every time. This reduces your test starting time as some of the signal configuration will take longer to generate the waveform.
- ◆ For generating the longer duration waveform as the RFSG memory size is limited.
- ◆ For testing your receiver for continuous signal reception.
- ◆ For receiver functionality verification tests that require longer duration of video to be played.
- ◆ For receiver sensitivity measurement (BER) for longer duration.

The figure below shows the front panel of the Example VI.



The toolkit configurations are same as specified in section 3.1.

This example requires the following additional input parameters.

1. **Waveform File Path** – The toolkit writes the generated waveform in a file specified by this file path control.
2. **Oversampling Enabled** – set this property value to TRUE if resampling is required.
3. **Output Sampling Rate (Hz)** – Configure this control to a suitable value if Oversampling Enabled property is set to TRUE.
4. **Sample Width** – The default sample width of the output waveform is 8-bits. The available options are 8-bits and 16-bits. We recommend 16-bits sample width for better signal quality of the generated waveform.

3.3. Play Waveform from File

This example reads the DVB-S2 waveform from the file created using the previous example in section 3.2 and then downloads the waveform in real-time to NI RFSG Memory and then plays the waveform. This example is created using the NI RFSG streaming example available in the NI website.


This example uses NI RFSG in streaming mode for playing the waveform in real-time. The performance of this example is related to the performance of your CPU and available RAM memory.

For more information please contact info@maxeyetech.com

The figure below shows the front panel of the Example VI. For more information about NI RFSG streaming refer to the web link below.

<http://zone.ni.com/reference/en-XX/help/371025K-01/rfsg/streaming/>

Sample Width – use the same sample width value used for storing the waveform in the file.



3.4 Play Waveform from File (USRP)


3.4.1 MaxEye DVB-S2 USRP Play Waveform from File

This example reads the DVB-S2 waveform from the file created using the example mentioned in the Section 3.2 and then downloads the waveform in real time to NI USRP memory and then plays the waveform.

The performance of this example is related to the performance of your CPU and available RAM memory.

The figure below shows the front panel of the Example VI.

For more information please contact info@maxeyetech.com



**MAXEYE
TECHNOLOGIES**

File Edit View Project Operate Tools Window Help

15pt Application Font Search

Playback Visualization About **Not Generating**

TX Destination File

TX USRP Configuration

USRP IP Address: 192.168.10.2

carrier frequency: 1.7G

IQ rate (S/s): 5M

gain: 0

active antenna: TX1

Write Buffer (IQ Samples): 10000

Sample Width: 16-bit

Total Playback Duration (s): **18.998**

Actual Coerced TX Values

USRP IP Address: 192.168.10.2

carrier frequency: 1.733G

IQ rate (S/s): 10M

gain: 5

active antenna: TX1

Write Buffer (IQ Samples): 10000


Sample Width: 16-bit

Start Generation

Start Generation

Stop Application <Esc>

For more information please contact info@maxeyetech.com



3.4.1.1 TX USRP Configuration

TX USRP Configuration

USRP IP Address
192.168.10.2

carrier frequency
1.7G

IQ rate (S/s)
5M

gain
0

active antenna
TX1

Write Buffer (IQ Samples)
10000

Sample Width
16-bit

USRP IP Address – IP address of the NI USRP

Carrier Frequency – Center Frequency of the DVB-S2 signal in Hz.

IQ Rate (S/s) – Rate of the baseband I/Q data in samples per second (S/s).

Sample Width – configure the sample width used to generate waveform file.

Active Antenna, Gain, Expected Peak, coerced IQ rare, coerced carrier frequency, and coerced gain
– Refer NI USRP help file.

3.4.1.2 Visualization

The spectrum of the generated waveform can be monitored in the Visualization Tab as in the example VI shown below. Enable Display button needs to be set to ON state in order to view the spectrum.

